


Instructions ULTRAK 360

FEATURES


- Time/Calendar display: Hour, minute, second, month, year, date and day
- Stopwatch: 1/100 second up to 10 hours
- 30 lap and split recorded
- Maximum 99 lap displayed
- Water resistant
- Bright LED backlight
- Alarm



- A: LAP/RESET
- B: RECALL
- C: MODE
- D: START/STOP
- E: EL LIGHT

DISPLAY SYMBOLS

Normal Time Mode



Lap Mode



Split Mode



Countdown Timer Mode




Alarm Mode



TIME /CALENDAR SETTING

1. Press button **C** to go to Normal Time Mode.
2. Press button **B** for 2 seconds, second digit flashing.
3. Press button **D** to reset the second to 00 when the second is less than 30, add 1 minute when the second is more than or equal to 30.
4. Press button **A** to change the setting items: minute-hour-12/24 hour-month-date-year.
5. Press button **D** to increase the setting value.
6. Press button **B** to exit.



ALARM SETTING MODE

1. From the normal time display, press button **C** 4 times to enter into Alarm mode.
2. Hold button **B** for 2 seconds, hour digit flashes
3. Press button **D** to increase the setting value.
4. Press button **A** to step the setting items.
5. Press button **D** to increase the value.
6. Press button **B** to exit.
7. Press button **D** to turn the alarm on or off.
8. Press button **C** to turn to the Normal Time Mode.


Note: When the alarm is sounding, it lasts for 1 minute. Press any button to stop it.

STOPWATCH MODE

Press button **C** to go to Lap Mode


Simple Measurement: **D-D-A**

Accumulated elapsed time Measurement: **D-D-D-D-A**




Lap Measurement (Total 30 lap memory measurement and 99 lap measurement)

For Example: 5 Lap measurement: Button **D-A-A-A-A-D**



Recall Memory

1. Press button **B** and then press button **A** to view different lap records. The display will run through in turn: Lap 1 > Lap 2 > Lap 3 > Lap 4 > Lap 5 > Lap 1
2. Press button **D** the display is reverse from above.




3. Press button **B** to go back to the Lap Mode.
4. Press button **A** to reset the value then start a new game.
5. To delete the records, press **D-D-A**.

Split Measurement

Press button **C** to go to Split mode.

For Example:5 splits measurement: Button **D-A-A-A-A-D**.



Recall Memory

1.Press button **B** and then press button **A** to view different splits records.

The display will run through in turn: Lap 1>Lap2>Lap 3> Lap4> Lap 5> Lap 1>



2.Press button **B** then press button **D** the display is reverse.

3.Press button **B** to turn to the Split Mode.

4.Press button **A** to reset the value then start a new game.

5.To delete the records, press **D-D-A**.

COUNTDOWN TIMER MODE

1.Press button **C** to go to the Countdown Timer Mode.

2.Hold button **B** for 2 seconds, hour digit flashes.

3.Press button **D** to increase the setting value.


4.Press button **A** to step the setting items.

5.Press button **D** to increase the value.

6.Press button **B** to finish setting the countdown time.

7.Press button **D** to start countdown.

8.When countdown reach zero, alarm will sound for 1 minute, press any button to stop it.



BATTERY REPLACEMENT

When the display becomes dim, change a new battery at once. Screw out the case back and change a new CR2032 battery. Pay attention to the correct polarity when changing battery.

CEI THREE YEAR LIMITED WARRANTY

CEI warrants this product (except for batteries) to be free from defects in materials and workmanship under normal use for three years from the date of purchase. CEI will, at its option, repair or replace the product free of charge. The warranty does not apply to damage caused by negligence, accident, misuse or repair. No responsibility is assumed for any incidental or consequential damages. Some states do not allow limitations on how long an implied warranty lasts and some states do not allow the exclusion or limitation of incidental or consequential damages, so that the above limitations may not apply. This warranty gives specific legal rights, and other rights may exist which vary from state to state. To obtain warranty service send the unit prepaid and insured, with dated proof of purchase, to: CEI, 550 Patrice Place, Unit C, Gardena, CA 90248.

WARNING	
<ul style="list-style-type: none"> ● INGESTION HAZARD: This product contains a button cell or coin battery. ● DEATH or serious injury can occur if ingested. ● A swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours. ● KEEP new and used batteries OUT OF REACH OF CHILDREN. ● Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body. 	

WARNING	
<ul style="list-style-type: none"> ● INGESTION HAZARD: This product contains a button cell or coin battery. ● DEATH or serious injury can occur if ingested. ● A swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours. ● KEEP new and used batteries OUT OF REACH OF CHILDREN. ● Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body. 	

STATEMENT

A)Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.

B)Even used batteries may cause severe injury or death.

C)Call a local poison control center for treatment information.

D)This product use battery type CR2032.

E)This product nominal battery voltage is 3V.

F)Non rechargeable batteries are not to be recharged.

G)Do not force discharge, recharge, disassemble, heat above 60°C or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.